


Connecting your Aquavision to Control 4 via IR Cable

Snap off the IR" tab from the IR Board as shown.
Should your IR board be an older version and not look like this, please contact your Aquavision office to arrange for a replacement board to be supplied.



 Plug a standard 3 pole 3.5mm jack to jack lead into the top socket marked "SKY"



- Download Aquavision Series 5 driver
 (Aquavision_Series 5_IR.c4i.) from the Control4 or
 Aquavision website and once installed, this will work correctly
- Please check the Control 4 driver is set to receive IR
 "Directly controlled with a wire" and boxes ticked as shown right.







HEAD OFFICE AND FACTORY

Aquavision
Unit 2 Grosvenor Business Park,
Horsfield way, Stockport,
Cheshire, SK6 2SU.
United Kingdom
+44 (0) 161 711 1900

AMERICAN OFFICE

Aquavision, Inc. #197 5 Southside Drive, Suite 11 Clifton Park, NY 12065 America +1 800 524 1804



sales@aquavision.tv sales@aquavision.us

www.aquavision.us