



# Aquavision Relay Interface Module AVF-5RLY4P

The Aquavision Relay Interface Module provides four multipurpose, potential free, relay contacts which become active when your Aquavision TV is switched on.

A Relay Interface Module can be fitted to any Genesis, Nexus, Pinnacle or Elite range television and is compatible with all installed models.


Simply connects to the Auxiliary interface connector on the television via a standard "ethernet" RJ45 lead.



Includes the following applications:

- Switching external speaker source from an Audio device to your Aquavision when it is switched on
- Status signal to external audio systems
- Status signal for control systems
- External control LED mirror lights
- External control mirror demisting pads
- Maximum power on each terminal is DC: 28V, 2A, 60W, AC 125V, 0.5A, 60 W
- Internal LED to show status of relay. ON for active, OFF for normal.

There is also a local DC socket inside the relay enabling it to be used with any "USB" fed power supply. This will automatically activate the relay when powered up. There is also a "jumper" inside that allows this to connect with older model Aquavision televisions where you need to also connect the ethernet cable to activate the relay.



## HEAD OFFICE AND FACTORY

Aquavision  
Unit 2 Grosvenor Business Park  
Horsfield Way, Stockport  
Cheshire, SK6 2SU  
United Kingdom  
+44 [0]161 711 900

## AMERICAN OFFICE

Aquavision, Inc.  
#197  
5 Southside Drive, Suite 11  
Clifton Park, NY 12065  
America  
+1 800 524 1804



[sales@aquavision.tv](mailto:sales@aquavision.tv)  
[sales@aquavision.us](mailto:sales@aquavision.us)

[www.aquavision.tv](http://www.aquavision.tv)  
[www.aquavision.us](http://www.aquavision.us)