

Hotel Mode for Pinnacle Televisions

Hotel Mode allows you to set features including:

- Initial Volume
- Maximum Volume
- Initial Channel
- Initial Picture Status Memory (PSM)
- Initial Sound Status Memory (SSM)

The table below shows you the button sequences you will need to access the necessary menus on your television.

Screen Version	Factory Settings Location
Series 4 A	Set Volume to 0 then press 9876
Series 4 B	Press INFO, STILL, SLEEP, MUTE and then ENTER
Genesis	Set Volume to 0 then press 9876
Genesis 2	
Nexus	Press SOURCE then press 2580
Pinnacle (Pre 2018 - Androud 4)	
Pinnacle (Post 2018 - Android 6)	Press SOURCE then press 1147
Elite 4K	Press MENU then either 1147 or 0852 or 4588
Genesis ATSC	
Nexus ATSC	Press SOURCE then press 2223
Pinnacle ATSC	

Exporting the Hotel Data Base

To export the Hotel Database, make sure a USB stick is inserted in the back of the television and in Hotel Mode, press the DOWN arrow 'DataBase Export' and press ENTER.

Choose the information you want to Export and then press the DOWN arrow until you get to 'Export data->' and then press ENTER

Eject the USB device from the television and insert it into a computer.



Importing the Hotel Data Base

To import the Hotel Database, make sure a USB stick is inserted in the back of the television and in Hotel Mode, press the DOWN arrow 'DataBase Import' and press ENTER.

You will then be able to select the items you want to import. Then press the DOWN arrow until you get to 'Import data->'. The TV will then restart.









